# METAL FRAMING TRUSS+
Modify Grid from Roof

AGACAD
TOOLS 4 BIM

Update Grid from Roof

- Select a grid.
- Choose *Update Grid from Roof* directly from "Truss+" menu.
- The grid will be automatically updated according to the roof geometry.

Update Grid from Roof

- If an error message 'Select Grid to modify' occurs, it means that the user hasn't selected grid before trying to update it.

Not selected grid

Selected grid

Error occured

⚠ Select Grid to modify.

OK

AGACAD
TOOLS 4 BIM

AGA CAD Ltd
T: +370 618 55671 | E: support@aga-cad.com | W: www.aga-cad.com